

**Tools Required:**


5/16" Masonry or Concrete Drill Bit  
Drill

**Notice to Installer:**

Anchors used in finished concrete applications only.

**79 825 anchorage installation:**

1. Establish location for installation on finished concrete.
2. Determine location of drill holes using the base plate of the fixture as a template.
3. Drill (2) 5/16" holes in concrete in alignment with the template.
4. Align base plate holes with the drill holes.
5. Drive anchors through the baseplate and into drill holes until they are seated flush.
6. To fasten, tighten acorn nuts.
7. Install fixture and make necessary wiring connections.
8. Secure fixture with set screws or bolts provided.



In the interest of product improvement, BEGA reserves the right to make technical changes without notice.