

Tools Required:

For small-scale floodlights

- 2.5mm hex key (for 5-1/2 ")
- 3mm hex key (for 6-1/4 " and 9 ")
- Medium slotted screwdriver

Louver accessory installation onto floodlights:

1. Loosen screws on outer luminaire faceplate trim.
2. Disassemble lens, gasket, and reflector.
3. Insert louver into center holes of the reflector. (figure 1)
4. Re-assemble lens, reflector and gasket; Make sure gasket is positioned correctly; (figure 2)
5. Close floodlight trim and tighten screws evenly and fully to secure.

NOTE: Louver may be used with other floodlight accessories.
Louver prevents glare in lateral direction up to 45°.

Figure 1





Figure 2



Accessories

Please refer to the appropriate accessory installation sheet for further instruction when applicable.

Louver:

5-1/2 " (LED)	70 760
5-1/2 "	70 785
6-1/4 " (LED)	70 796
6-1/4 "	70 797
9 "	70 798