


Tools Required:

- 3mm hexagon socket wrench



Dimensions

- A: 4-3/4"  
B: 6-7/8"



Protection Class: N/A

Weight: 0.5lbs

Notice to Installer for 71 111:

1. See page 2 for specific product safety warnings.
2. The glare shield can be rotated 360°, prevents lateral glare from one direction up to 45°.
3. Suitable for Bega floodlights:  
84 504 • 84 505 • 84 506 • 84 526 • 84 527 • 84 528

71 111 - Lens Installation:

1. Using 3mm hexagon socket wrench, undo the hexagon screw [Figure 1] and insert the shield into the groove in the floodlight housing.
2. Align the glare shield as needed and secure it in place by tightening hexagon socket screw.

Figure 1:





Figure 2:



Maintenance

Clean regularly with solvent-free cleaner removing dirt and debris.

Do not use high pressure cleaners.

Accessories

Please refer to the appropriate accessory installation sheet for further instruction when applicable.

Replacement Parts

## Product Safety Warnings:

**THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED. SUITABLE FOR WET LOCATIONS.**

**MIN 90°C SUPPLY CONDUCTORS.**

**CE PRODUIT DOIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAÎT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS. CONVIENT AUX EMPLACEMENTS MOUILLÉS.**

**LES FILS D'ALIMENTATION 90°C MIN.**